



TAYCO DESIGNS
SCROLLSAWVIDEO.COM



Thank you for your purchase.

Materials needed

1/8 or 1/4 inch wood of choice

#2 or #3 scroll saw blade

1/16 inch or smaller drill bit

Spray adhesive

Finish of choice

Make a copy of the pattern.

Apply pattern to wood with spray adhesive

Drill starter holes in gray areas

**Proceed to cut starting with the center and
work towards the outside.**

Remove pattern from wood

Finish and frame of choice.





